## All Cameras Have an Issue Does the server have power? No Perform a power drain on the server: Does pressing the server's power button boot it up? Shut down the server 1) 2) Unplug the black power cable from the back of the server Yes No 3) Press the power button ten times 4) Wait 1 min and plug back in 5) Power the server back on Is the battery backup for the server powered on with all power cables securely plugged in? Did the power drain Yes correct the issue? No Does holding the power No button (until it beeps) turn on the battery backup? Check the camera power Yes No supply box. Verify that it has power Will the server (there should be green lights boot up, with the near each fuse) issue resolved? If it does not, make sure that it is plugged and turned on. Did this resolve the issue? No Close the Control Center and attempt to browse the internet with Google Chrome, Internet Explorer or Make note of what Microsoft Edge. Make note of your step you were on browsing results. and contact Maintenance.