Only Some Cameras Have an Issue Is the associated DVR powered on? Yes No Power down the DVR for 1 min and power Does pressing the DVR's power button boot it up? it back up Yes No Does this resolve this issue? Is the battery backup for the DVR No powered on, with all power cables securely plugged in? Perform a power drain on the server: 1) Shut down the server No Yes 2) Unplug the black power cable from the back of the server Does holding the power button 3) Press the power button ten times (until it beeps) power up the 4) Wait 1 min and plug back in battery backup? 5) Power the server back on Yes No Did the power drain correct the issue? Does this resolve the issue? No Check the camera power supply box. Verify that it has power (there should be green lights near each fuse) If it does not, make sure that it is plugged and turned on. Did this resolve the issue? No Check power Make note of what step breakers in the you were on and contact areas of the cameras Maintenance. that will not display.