

Report for:

Richard Walters Bixby Public Schools 109 N. Armstrong Bixby, OK 74008

Regarding: Project: Central Intermediate; Multi-Room Test

EML ID: 2590281

Approved by:

Dates of Analysis:

Spore trap analysis: 03-09-2021

Laboratory Manager Michael Manning

Service SOPs: Spore trap analysis (EM-MY-S-1038) AIHA-LAP, LLC accredited service, Lab ID #193549

All samples were received in acceptable condition unless noted in the Report Comments portion in the body of the report. Due to the nature of the analyses performed, field blank correction of results is not applied. The results relate only to the samples as received and tested. Sample air volume is supplied by the client.

Eurofins EMLab P&K ("the Company") shall have no liability to the client or the client's customer with respect to decisions or recommendations made, actions taken or courses of conduct implemented by either the client or the client's customer as a result of or based upon the Test Results. In no event shall the Company be liable to the client with respect to the Test Results except for the Company's own willful misconduct or gross negligence nor shall the Company be liable for incidental or consequential damages or lost profits or revenues to the fullest extent such liability may be disclaimed by law, even if the Company has been advised of the possibility of such damages, lost profits or lost revenues. In no event shall the Company's liability with respect to the Test Results exceed the amount paid to the Company by the client therefor.

Eurofins EMLab P&K's LabServe® reporting system includes automated fail-safes to ensure that all AIHA-LAP, LLC quality requirements are met and notifications are added to reports when any quality steps remain pending.

Eurofins EMLab P&K

10900 Brittmoore Park Drive, Suite G, Houston, TX 77041 (800) 651-4802 Fax (623) 780-7695 www.emlab.com

Client: Bixby Public Schools
C/O: Richard Walters
Date of Sampling: 03-04-2021
Date of Receipt: 03-05-2021
Date of Report: 03-09-2021

SPORE TRAP REPORT: NON-VIABLE METHODOLOGY

Location:	1: Pre Outside Air			2:			3:		
				Rm 209			Rm 211		
Comments (see below)	None			None			None		
Lab ID-Version‡:	12359266-1			12359267-1			12359268-1		
Analysis Date:	03/09/2021			03/09/2021			03/09/2021		
	raw ct.	adj. ct.	spores/m3	raw ct.	adj. ct.	spores/m3	raw ct.	adj. ct.	spores/m3
Alternaria	4	4	27	1	1	7	2	2	13
Ascospores									
Basidiospores	7	28	190	5	20	130	3	12	80
Botrytis									
Chaetomium									
Cladosporium	11	44	290	8	32	210	2	8	53
Curvularia									
Epicoccum	2	2	13	1	1	7	2	2	13
Fusarium									
Myrothecium									
Nigrospora									
Other brown							1	1	7
Other colorless	1	1	7						
Penicillium/Aspergillus types†	22	88	590	1	4	27			
Pithomyces									
Rusts									
Smuts, Periconia, Myxomycetes	1	1	7				2	2	13
Stachybotrys									
Stemphylium									
Torula									
Ulocladium									
Zygomycetes									
Background debris (1-4+)††	2+			1+			2+		
Sample volume (liters)	150			150			150		
§ TOTAL SPORES/m3			1,100			390			180

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

[†] The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

^{††}Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

[‡] A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

[§] Total Spores/m3 has been rounded to two significant figures to reflect analytical precision.

Eurofins EMLab P&K

10900 Brittmoore Park Drive, Suite G, Houston, TX 77041 (800) 651-4802 Fax (623) 780-7695 www.emlab.com

Client: Bixby Public Schools

C/O: Richard Walters

Re: Central Intermediate; Multi-Room Test

Date of Sampling: 03-04-2021

Date of Receipt: 03-05-2021

Date of Report: 03-09-2021

SPORE TRAP REPORT: NON-VIABLE METHODOLOGY

Location:	4: Rm 215			5: Rm 216			6: Post Outside Air		
Comments (see below)	None			None			None Post Outside Air		
Lab ID-Version‡:									
•	12359269-1			12359270-1			12359271-1		
Analysis Date:	03/09/2021			03/09/2021			03/09/2021		
	raw ct.	adj. ct.	spores/m3	raw ct.	adj. ct.	spores/m3			spores/m3
Alternaria							4	4	27
Ascospores							2	8	53
Basidiospores							5	20	130
Botrytis									
Chaetomium							1	1	7
Cladosporium	4	16	110				2	8	53
Curvularia									
Epicoccum	1	1	7	1	1	7			
Fusarium									
Myrothecium									
Nigrospora									
Other brown									
Other colorless									
Penicillium/Aspergillus types†							1	4	27
Pithomyces									
Rusts									
Smuts, Periconia, Myxomycetes							1	1	7
Stachybotrys									
Stemphylium									
Torula									
Ulocladium									
Zygomycetes									
Background debris (1-4+)††	4+			< 1+			2+		
Sample volume (liters)	150			150			150		
§ TOTAL SPORES/m3			110			7			310

Comments:

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

The analytical sensitivity is the spores/m³ divided by the raw count, expressed in spores/m³. The limit of detection is the analytical sensitivity (in spores/m³) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

[†] The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

^{††}Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

[‡] A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

[§] Total Spores/m3 has been rounded to two significant figures to reflect analytical precision.